
MIC
TEL IN
LINE
INSERT
M1
M2
M3
M4
CLF OUT
TELCO 1
TELCO 2
ST2
ST4
REC OUT
CRM SPEAKERS
MIX B OUT
INSERT L
INSERT R
MAIN PGM OUT
L/M
ST1
ST3
ST5
ST7
EXT MON IN
AUX
MONO OUT
GAIN
HF
MF
LF
PRE
AUX
MIX B BUS
PAN
BAL
REM MUTE
PEAK
SIGNAL
PFL
PGM FDR
+START/CUE
TALK
CLF SCE
PGM
USB
T1
T2
USB RTN
ST6 (USB)
5/USB
1/2
3/4
GUEST PHONES 1
GUEST PHONES 2
CRM PHONES
USB SEND
RETURN
AUX+MONO
USB SOURCE SELECT
MIX B
PGM MIX
48V
PHANTOM POWER TO MICS
POWER
XB 14
PFL ACTIVE
CRM PHONES SELECTION
GUEST PHONES SELECTION
USB IN
EXT MON
ALLEN&HEATH
CRM SPEAKERS
MIN
MAX
PFL ENABLE TO GUEST
DIM SPKS
TALK TO GUEST
CUT SPKS
MIC FADER UP =CUT SPKS
CRM PHONES
GUEST PHONES
MIX B LEVEL
PGM MIX FADER
PGM